

## Phones with Memory Card Slots

August 22, 2007

Device compatibility information source: Independent on-line review or device manufacturer press release, brochure, product manual or other 3rd party source. Please check with your device manufacturer for details.

<i>Brand</i>	<i>Model</i>	<i>Media</i>	<i>Camera</i>	<i>Video</i>	<i>Music</i>
Alcatel	ELLE No 3	microSD	YES	YES	YES
Alcatel	OT-C507	microSD	YES	NO	NO
Alcatel	OT-C701	microSD	YES	YES	YES
Alcatel	OT-C707	microSD	YES	YES	YES
Alcatel	OT-C717	microSD	YES	YES	YES
Alcatel	OT-C825	microSD	YES	YES	YES
Alcatel	OT-E805	microSD	NO	NO	YES
Amoi	A865	microSD	YES	YES	YES
Amoi	H8	microSD	YES	YES	YES
Amoi	H80	microSD	YES	YES	YES
Amoi	H801	microSD	YES	YES	YES
Amoi	H802	microSD	YES	YES	YES
Amoi	M650	microSD	YES	YES	YES
Amoi	V810	microSD	YES	YES	YES
Asus	M303	miniSD	YES	YES	YES
Asus	M307	miniSD	YES	YES	YES
Asus	P505i	SD	YES	YES	NO
Asus	P525	miniSD	YES	YES	YES
Asus	P535	miniSD	YES	YES	YES
Asus	V66	miniSD	YES	YES	YES
Asus	V75	miniSD	YES	YES	YES
Asus	V80	miniSD	YES	YES	YES
Asus	Z801	microSD	YES	YES	YES
Asus	Z810	microSD	YES	YES	NO
Benefon	TWIG Discovery	miniSD	NO	NO	NO
BenQ	C81	MMCmobile	YES	YES	YES
BenQ	CF61	microSD	YES	YES	YES
BenQ	CL71	microSD	YES	YES	YES
BenQ	D870	microSD	YES	YES	YES
BenQ	E-61	miniSD	YES	YES	YES
BenQ	EF81	microSD	YES	YES	YES
BenQ	EL71	microSD	YES	YES	YES
BenQ	P51	SD	YES	YES	YES
BenQ	S88	microSD	YES	YES	YES
BenQ-Siemens	E71	microSD	YES	YES	YES
BenQ-Siemens	E81	microSD	YES	YES	YES
BenQ-Siemens	EF61	microSD	YES	YES	YES
BenQ-Siemens	EF71	microSD	YES	YES	YES
BenQ-Siemens	M81	RS-MMC	YES	YES	YES
BenQ-Siemens	SL91	microSD	YES	YES	YES
Bird	D660	microSD	YES	YES	YES
Casio Hitachi	W43CA	microSD	YES	YES	YES

<b>Brand</b>	<b>Model</b>	<b>Media</b>	<b>Camera</b>	<b>Video</b>	<b>Music</b>
Casio Hitachi	W43H	microSD	YES	YES	YES
Cingular	3125	microSD	YES	YES	YES
Cingular	8525	microSD	YES	YES	YES
Cingular	SYNC	microSD	YES	YES	YES
Compal	AR-11	SD	NO	NO	YES
Eten	glofiish M700	microSD	YES	YES	YES
Eten	glofiish X500	microSD	YES	YES	YES
Eten	M600+	SD	YES	YES	YES
Eten	M700	microSD	YES	YES	YES
Fujitsu	F903i	microSD	NO	NO	NO
Fujitsu Siemens	Pocket LOOX T830	SD	YES	YES	YES
Gigabyte	g-Smart i120	miniSD	YES	YES	YES
Gigabyte	g-Smart i300	miniSD	YES	YES	YES
Gigabyte	g-YoYo	miniSD	YES	YES	YES
Haier	A600	microSD	YES	YES	YES
Haier	Black Pearl	microSD	NO	NO	YES
Haier	M260	miniSD	YES	YES	YES
Haier	M80	miniSD	YES	YES	YES
Haier	N-70	microSD	YES	YES	YES
Haier	N-90	miniSD	YES	YES	YES
HP	iPAQ hw6900	miniSD	YES	YES	YES
HP iPAQ	rw6815	miniSD	YES	YES	YES
HTC	Advantage	miniSD	YES	YES	YES
HTC	FOREseer	microSD	YES	YES	YES
HTC	Mogul	microSD	YES	YES	YES
HTC	MTeoR	microSD	YES	YES	YES
HTC	P3300	microSD	YES	YES	YES
HTC	P3350	microSD	YES	YES	YES
HTC	P3400	SD	YES	YES	YES
HTC	P3600	miniSD	YES	YES	YES
HTC	P4350	microSD	YES	YES	YES
HTC	P4550	microSD	YES	YES	YES
HTC	P6300	SD	YES	YES	YES
HTC	S310	miniSD	YES	YES	YES
HTC	S620	microSD	YES	YES	YES
HTC	S630	microSD	YES	YES	YES
HTC	S710	microSD	YES	YES	YES
HTC	Shift	miniSD	YES	YES	YES
HTC	Touch	microSD	YES	YES	YES
HTC	TyTN	microSD	YES	YES	YES
HUAWEI	U526	miniSD	YES	YES	YES
i-mate	JAMin	SD	YES	YES	YES
i-mate	JAQ	miniSD	NO	YES	YES
i-mate	JAQ	miniSD	NO	YES	YES
i-mate	JAQ3	microSD	YES	YES	YES
i-mate	JASJAM	miniSD	YES	YES	YES

<i>Brand</i>	<i>Model</i>	<i>Media</i>	<i>Camera</i>	<i>Video</i>	<i>Music</i>
i-mate	PDAL	microSD	YES	YES	YES
i-mate	Smartflip	microSD	YES	YES	YES
i-mate	SPJAS	microSD	YES	YES	YES
i-mate	SPL	miniSD	YES	YES	YES
KTFT	KTF-T1500	microSD	YES	YES	YES
KTFT	KTF-T3000	microSD	YES	NO	YES
KTFT	KTF-T7000	microSD	YES	YES	YES
Kyocera	W43K	microSD	YES	YES	YES
LG	CE500	microSD	YES	YES	YES
LG	CU320	microSD	YES	YES	YES
LG	CU400	microSD	YES	YES	YES
LG	CU500	microSD	YES	YES	YES
LG	KE600	microSD	YES	YES	YES
LG	KE770 Shine	microSD	YES	YES	YES
LG	KE800	microSD	YES	YES	YES
LG	KE820	microSD	YES	YES	YES
LG	KE850 Prada	microSD	YES	YES	YES
LG	KE970 Shine	microSD	YES	YES	YES
LG	KG200	microSD	YES	YES	YES
LG	KG300	microSD	YES	YES	YES
LG	KG330	microSD	YES	YES	YES
LG	KG920	miniSD	YES	YES	YES
LG	KS10	microSD	YES	YES	YES
LG	KU250	microSD	YES	YES	YES
LG	KU730	microSD	YES	YES	YES
LG	KU800	microSD	YES	YES	YES
LG	KU950	microSD	YES	YES	YES
LG	L600v	microSD	YES	YES	YES
LG	LX-550	microSD	YES	YES	YES
LG	Muziq	microSD	YES	YES	YES
LG	Trax	microSD	YES	YES	YES
LG	U300	microSD	YES	YES	YES
LG	U310	microSD	YES	YES	YES
LG	U400	microSD	YES	YES	YES
LG	U8500	microSD	YES	YES	YES
LG	U8550	microSD	YES	YES	YES
LG	U890	microSD	YES	YES	YES
LG	U900	microSD	YES	YES	YES
LG	VX8300	miniSD	YES	YES	YES
LG	VX8500 (Chocolate)	microSD	YES	YES	YES
LG	VX8550 (Chocolate)	microSD	YES	YES	YES
LG	VX8600	microSD	YES	YES	YES
LG	VX8700	microSD	YES	YES	YES
LG	VX9400	microSD	YES	YES	YES
LG	VX9900 (enV)	microSD	YES	YES	YES
LG Cyon	LG-KB1500	microSD	YES	NO	YES

<b>Brand</b>	<b>Model</b>	<b>Media</b>	<b>Camera</b>	<b>Video</b>	<b>Music</b>
LG Cyon	LG-KD1200	microSD	YES	NO	YES
LG Cyon	LG-KP4700	microSD	YES	YES	YES
LG Cyon	LG-KW9200	microSD	YES	NO	YES
LG Cyon	LG-LB1500	microSD	YES	NO	YES
LG Cyon	LG-SC300	microSD	YES	NO	YES
LG Cyon	LG-SV360	miniSD	YES	NO	YES
Mio	A710	SD	YES	YES	YES
Mitsubishi	F903iX	microSD	NO	NO	NO
Motorola	i880	microSD	YES	YES	YES
Motorola	KRZR K1	microSD	YES	YES	YES
Motorola	KRZR K1m	microSD	YES	YES	YES
Motorola	KRZR K3	microSD	YES	YES	YES
Motorola	L7e	MicroSD	YES	YES	YES
Motorola	MS-600	microSD	YES	YES	YES
Motorola	POKR E2	SD	YES	YES	YES
Motorola	Q	miniSD	YES	YES	YES
Motorola	Q 9h	microSD	YES	YES	YES
Motorola	Q Pro	miniSD	YES	YES	YES
Motorola	Q q9	microSD	YES	YES	YES
Motorola	RAZR maxx	microSD	YES	YES	YES
Motorola	RAZR MAXX V6	microSD	YES	YES	YES
Motorola	RAZR MAXX Ve	microSD	YES	YES	YES
Motorola	RAZR V3m	microSD	YES	YES	YES
Motorola	RAZR V3r	miniSD	YES	YES	YES
Motorola	RAZR V3t	microSD	YES	YES	YES
Motorola	RAZR V3xx	microSD	YES	YES	YES
Motorola	RAZR2 V9	microSD	YES	YES	YES
Motorola	RIZR	microSD	YES	YES	YES
Motorola	RIZR Z3	microSD	YES	YES	YES
Motorola	RIZR Z6	microSD	YES	YES	YES
Motorola	RIZR Z8	microSD	YES	YES	YES
Motorola	ROKR E2	SD	YES	YES	YES
Motorola	ROKR E6	SD	YES	YES	YES
Motorola	ROKR Z6m	microSD	YES	YES	YES
Motorola	SLVR L7e	microSD	YES	YES	YES
Motorola	SLVR L9	microSD	YES	YES	YES
Motorola	V360	microSD	YES	YES	YES
Motorola	W395	microSD	YES	YES	YES
Motorola	W510	microSD	YES	YES	YES
NEC	705N	microSD	NO	NO	NO
NEC	804N	microSD	YES	YES	YES
NEC	e636	miniSD	YES	YES	YES
NEC	N903i	microSD	YES	NO	NO
NEC	N908	microSD	YES	YES	YES
Nokia	3109	microSD	NO	NO	YES
Nokia	3110c	microSD	YES	YES	YES

<b>Brand</b>	<b>Model</b>	<b>Media</b>	<b>Camera</b>	<b>Video</b>	<b>Music</b>
Nokia	3500	microSD	YES	YES	YES
Nokia	5200	microSD	YES	YES	YES
Nokia	5300	microSD	YES	YES	YES
Nokia	5500	microSD	YES	YES	NO
Nokia	5700	microSD	YES	YES	YES
Nokia	6085	microSD	YES	YES	YES
Nokia	6086	microSD	YES	YES	YES
Nokia	6110 Navigator	microSD	YES	YES	YES
Nokia	6120	microSD	YES	YES	YES
Nokia	6121	microSD	YES	YES	YES
Nokia	6125	microSD	YES	YES	YES
Nokia	6131	microSD	YES	YES	YES
Nokia	6133	microSD	YES	YES	YES
Nokia	6136	microSD	YES	YES	YES
Nokia	6151	microSD	YES	YES	YES
Nokia	6267	microSD	YES	YES	YES
Nokia	6275	microSD	YES	YES	YES
Nokia	6288	miniSD	YES	YES	YES
Nokia	6288	microSD	YES	YES	YES
Nokia	6290	microSD	YES	YES	YES
Nokia	6300	microSD	YES	YES	YES
Nokia	6315i	microSD	YES	NO	YES
Nokia	6500	microSD	YES	YES	YES
Nokia	6555	microSD	YES	NO	YES
Nokia	7373	microSD	YES	YES	YES
Nokia	7390	microSD	YES	YES	YES
Nokia	7500	microSD	YES	YES	YES
Nokia	7900	microSD	YES	YES	YES
Nokia	E50	microSD	YES	YES	YES
Nokia	E61i	microSD	YES	YES	YES
Nokia	E62	miniSD	No	YES	YES
Nokia	E65	microSD	YES	YES	YES
Nokia	E90	microSD	YES	YES	YES
Nokia	N72	MMCmobile	YES	YES	YES
Nokia	N73	miniSD	YES	YES	YES
Nokia	N75	microSD	YES	YES	YES
Nokia	N76	microSD	YES	YES	YES
Nokia	N77	microSD	YES	YES	YES
Nokia	N93	miniSD	YES	YES	YES
Nokia	N93i	miniSD	YES	YES	YES
Nokia	N95	microSD	YES	YES	YES
O2	XDA Atom Exec	miniSD	YES	YES	YES
O2	XDA Graphite	microSD	YES	YES	YES
O2	XDA Neo	SD	YES	YES	YES
O2	XDA Stealth	miniSD	Yes	Yes	Yes
O2	XDA Trion	miniSD	YES	YES	YES

<b>Brand</b>	<b>Model</b>	<b>Media</b>	<b>Camera</b>	<b>Video</b>	<b>Music</b>
O2	XDA Zinc	miniSD	YES	YES	YES
Orange	SPV C700	microSD	YES	YES	YES
Orange	SPV M3100	microSD	YES	YES	YES
Palm	Treo 680	SD	YES	YES	YES
Palm	Treo 700p	SD	YES	YES	YES
Palm	Treo 700wx	SD	YES	YES	YES
Palm	Treo 750	miniSD	YES	YES	YES
Palm	Treo 750v	miniSD	YES	YES	YES
Palm	Treo 755p	miniSD	YES	YES	YES
Pantech	PG-1800	microSD	YES	YES	YES
Pantech	PG-1900	microSD	YES	YES	YES
Pantech	PG-3600V	microSD	YES	YES	YES
Pantech	PG-3900	microSD	YES	YES	YES
Pantech	PG-6200	microSD	YES	YES	YES
Pantech	PN-8300	microSD	YES	YES	YES
Pantech	PU-5000	microSD	YES	YES	YES
Pantech	U-400	microSD	YES	YES	YES
Philips	680	miniSD	YES	YES	YES
Philips	S900	miniSD	YES	YES	YES
Philips	Xenium 9@9t	miniSD	YES	YES	YES
PMC	705P	microSD	NO	NO	NO
PMC	P903i	microSD	NO	NO	NO
PMC	P903iTV	microSD	NO	NO	NO
PMC	P903iX?	microSD	NO	NO	NO
Qtec	8500	microSD	YES	YES	YES
Qtec	8600	microSD	YES	YES	YES
Qtec	9600	miniSD	YES	YES	YES
Qtec	S200	SD	YES	YES	YES
RIM	(Curve)	microSD	YES	YES	YES
RIM	BlackBerry 8800	microSD	NO	YES	YES
RIM	BlackBerry 8820	microSD	NO	NO	YES
RIM	BlackBerry 8830	microSD	NO	NO	YES
RIM	BlackBerry Pearl	microSD	YES	YES	YES
Sagem	my500X	miniSD	YES	YES	YES
Sagem	my501c	microSD	YES	YES	YES
Sagem	my600v	miniSD	YES	YES	YES
Samsung	BlackJack	microSD	YES	YES	YES
Samsung	Drift	microSD	YES	YES	YES
Samsung	SCH-A930	microSD	YES	YES	YES
Samsung	SCH-A990	microSD	YES	YES	YES
Samsung	SCH-B340	microSD	YES	YES	YES
Samsung	SCH-B380	microSD	YES	YES	YES
Samsung	SCH-B600	MMCmicro	YES	YES	YES
Samsung	SCH-i760	microSD	YES	YES	YES
Samsung	SCH-i830	SD	NO	YES	YES
Samsung	SCH-U510	microSD	YES	YES	YES

<b>Brand</b>	<b>Model</b>	<b>Media</b>	<b>Camera</b>	<b>Video</b>	<b>Music</b>
Samsung	SCH-U520	microSD	YES	YES	YES
Samsung	SCH-U620	microSD	YES	YES	YES
Samsung	SCH-U740	microSD	YES	YES	YES
Samsung	SCH-V735	microSD	NO	NO	NO
Samsung	SCH-V840	microSD	YES	YES	YES
Samsung	SCH-V870	microSD	YES	YES	YES
Samsung	SGH-A517	microSD	YES	YES	YES
Samsung	SGH-A701	microSD	YES	YES	YES
Samsung	SGH-A707	microSD	YES	YES	YES
Samsung	SGH-A717	microSD	YES	YES	YES
Samsung	SGH-A727	microSD	YES	YES	YES
Samsung	SGH-D830	microSD	YES	YES	YES
Samsung	SGH-D840	microSD	YES	YES	YES
Samsung	SGH-D848	microSD	YES	YES	YES
Samsung	SGH-D900	microSD	YES	YES	YES
Samsung	SGH-D908	microSD	YES	YES	YES
Samsung	SGH-E250	microSD	YES	YES	YES
Samsung	SGH-E390	microSD	YES	YES	YES
Samsung	SGH-E480	microSD	YES	YES	YES
Samsung	SGH-E490	microSD	YES	YES	YES
Samsung	SGH-E570	microSD	YES	YES	YES
Samsung	SGH-E590	microSD	YES	YES	YES
Samsung	SGH-E690	microSD	YES	YES	YES
Samsung	SGH-E740	microSD	YES	YES	YES
Samsung	SGH-E770	microSD	YES	YES	YES
Samsung	SGH-E830	microSD	YES	YES	YES
Samsung	SGH-E840	microSD	YES	YES	YES
Samsung	SGH-E890	microSD	YES	YES	YES
Samsung	SGH-E898	microSD	YES	YES	YES
Samsung	SGH-E900	microSD	YES	YES	YES
Samsung	SGH-F300	microSD	YES	YES	YES
Samsung	SGH-F500	microSD	YES	YES	YES
Samsung	SGH-F510	microSD	YES	YES	YES
Samsung	SGH-F520	microSD	YES	YES	YES
Samsung	SGH-F700	microSD	YES	YES	YES
Samsung	SGH-i300x	microSD	YES	YES	YES
Samsung	SGH-i310	microSD	YES	YES	YES
Samsung	SGH-i320N	microSD	YES	YES	YES
Samsung	SGH-i520	microSD	YES	YES	YES
Samsung	SGH-i600	microSD	YES	YES	YES
Samsung	SGH-i710	microSD	YES	YES	YES
Samsung	SGH-i750	miniSD	YES	YES	YES
Samsung	SGH-P310	microSD	YES	YES	YES
Samsung	SGH-P920	microSD	YES	YES	YES
Samsung	SGH-P930	microSD	YES	YES	YES
Samsung	SGH-P940	microSD	YES	YES	YES

<b>Brand</b>	<b>Model</b>	<b>Media</b>	<b>Camera</b>	<b>Video</b>	<b>Music</b>
Samsung	SGH-S501i	microSD	YES	NO	YES
Samsung	SGH-T519 Trace	microSD	YES	YES	YES
Samsung	SGH-T609	microSD	YES	YES	YES
Samsung	SGH-T629	microSD	YES	YES	YES
Samsung	SGH-T729	microSD	YES	YES	YES
Samsung	SGH-U600	microSD	YES	YES	YES
Samsung	SGH-U700	microSD	YES	YES	YES
Samsung	SGH-X520	microSD	YES	NO	NO
Samsung	SGH-Z230	microSD	YES	YES	YES
Samsung	SGH-Z240	microSD	YES	YES	YES
Samsung	SGH-Z370	microSD	YES	YES	YES
Samsung	SGH-Z400	microSD	YES	YES	YES
Samsung	SGH-Z550	microSD	YES	YES	YES
Samsung	SGH-Z620	microSD	YES	YES	YES
Samsung	SGH-Z650i	microSD	YES	YES	YES
Samsung	SGH-Z710	microSD	YES	YES	YES
Samsung	SGH-Z720	microSD	YES	YES	YES
Samsung	SGH-ZX10	microSD	YES	YES	YES
Samsung	SGH-ZX20	microSD	YES	YES	YES
Samsung	SPH-3200	microSD	YES	YES	YES
Samsung	SPH-B2300	microSD	YES	YES	YES
Samsung	SPH-B3000	microSD	YES	YES	YES
Samsung	SPH-B3100	microSD	YES	YES	YES
Samsung	SPH-B3200	microSD	YES	NO	YES
Samsung	SPH-B5200	microSD	NO	NO	YES
Samsung	SPH-M300	microSD	YES	NO	NO
Samsung	SPH-M500	microSD	YES	YES	YES
Samsung	SPH-M510	microSD	YES	YES	YES
Samsung	SPH-M610	microSD	YES	YES	YES
Samsung	SPH-M620 (UpStage)	microSD	YES	YES	YES
Samsung	SPH-V8200	microSD	YES	YES	YES
Samsung	ZV40	microSD	YES	YES	YES
Samsung	ZV50	microSD	YES	YES	YES
Sanyo	A5522SA	microSD	YES	YES	NO
Sanyo	Katana DLX	microSD	YES	YES	YES
Sanyo	SCP-8400	microSD	YES	YES	YES
Sanyo	W42SA	microSD	YES	YES	YES
Sanyo	W43SA	microSD	YES	YES	YES
Sharp	550SH	microSD	YES	YES	YES
Sharp	705SH	microSD	YES	YES	YES
Sharp	770SH	microSD	YES	YES	YES
Sharp	810SH(J-410)	microSD	NO	NO	NO
Sharp	811SH(J-411)	microSD	NO	NO	NO
Sharp	904	miniSD	YES	YES	YES
Sharp	910SH	microSD	NO	NO	NO
Sharp	GX-40	miniSD	YES	YES	YES

<b>Brand</b>	<b>Model</b>	<b>Media</b>	<b>Camera</b>	<b>Video</b>	<b>Music</b>
Sharp	SH903i	microSD	NO	NO	NO
Sharp	SH903iTV	microSD	NO	YES	NO
Sharp	W41SH	microSD	YES	YES	YES
SKY Teletch	IM-S100	microSD	YES	NO	YES
SKY Teletch	IM-U100	microSD	YES	YES	YES
Sony Ericsson	K530i	M2	YES	YES	YES
Sony Ericsson	K550i	M2	YES	YES	YES
Sony Ericsson	K550im	M2	YES	YES	YES
Sony Ericsson	K618	M2	YES	YES	YES
Sony Ericsson	K618i	M2	YES	YES	YES
Sony Ericsson	K770i	M2	YES	YES	YES
Sony Ericsson	K790i	M2	YES	YES	YES
Sony Ericsson	K800i	M2	YES	YES	YES
Sony Ericsson	K810i	M2	YES	YES	YES
Sony Ericsson	K850i	microSD/M2	YES	YES	YES
Sony Ericsson	M600i	M2	No	YES	YES
Sony Ericsson	M608i	M2	NO	NO	YES
Sony Ericsson	P1i	M2	YES	YES	YES
Sony Ericsson	P990i	MS Pro Duo	YES	YES	YES
Sony Ericsson	S500i	M2	YES	YES	YES
Sony Ericsson	S550i	M2	YES	YES	YES
Sony Ericsson	T650i	M2	YES	YES	YES
Sony Ericsson	V630	M2	YES	YES	YES
Sony Ericsson	W200a	M2	YES	YES	YES
Sony Ericsson	W300i	M2	YES	YES	YES
Sony Ericsson	W43S	MS Pro Duo	YES	YES	YES
Sony Ericsson	W580i	M2	YES	YES	YES
Sony Ericsson	W610i	M2	YES	YES	YES
Sony Ericsson	W660i	M2	YES	YES	YES
Sony Ericsson	W700	MS Pro Duo	YES	YES	YES
Sony Ericsson	W700c	MS Pro Duo	YES	YES	YES
Sony Ericsson	W700i	MS Pro Duo	YES	YES	YES
Sony Ericsson	W710c	M2	YES	YES	YES
Sony Ericsson	W710i	M2	YES	YES	YES
Sony Ericsson	W710i	M2	YES	YES	YES
Sony Ericsson	W810i	MS Pro Duo	YES	YES	YES
Sony Ericsson	W830	MS Pro Duo	YES	YES	YES
Sony Ericsson	W850i	MS Pro Duo	YES	YES	YES
Sony Ericsson	W880i	M2	YES	YES	YES
Sony Ericsson	W888	M2	YES	YES	YES
Sony Ericsson	W910i	M2	YES	YES	YES
Sony Ericsson	Z200a	M2	YES	YES	YES
Sony Ericsson	Z530i	M2	YES	YES	YES
Sony Ericsson	Z550a	M2	YES	YES	YES
Sony Ericsson	Z550i	M2	YES	YES	YES
Sony Ericsson	Z558	M2	YES	YES	YES

<b>Brand</b>	<b>Model</b>	<b>Media</b>	<b>Camera</b>	<b>Video</b>	<b>Music</b>
Sony Ericsson	Z558i	M2	YES	YES	YES
Sony Ericsson	Z610i	M2	YES	YES	YES
Sony Ericsson	Z710i	M2	YES	YES	YES
Sony Ericsson	Z750i	M2	YES	YES	YES
Telit	t650	microSD	YES	YES	YES
Telit	t800	miniSD	YES	YES	YES
T-Mobile	Dash	microSD	YES	YES	YES
T-Mobile	MDA Vario II	microSD	YES	YES	YES
T-Mobile	Sidekick 3	miniSD	YES	NO	YES
T-Mobile	Wing	microSD	YES	YES	YES
Toshiba	705T	miniSD	YES	YES	YES
Toshiba	810T	microSD	NO	NO	NO
Toshiba	811T	microSD	NO	NO	NO
Toshiba	904T	miniSD	YES	YES	YES
Toshiba	910T	microSD	NO	NO	NO
Toshiba	DRAPE	microSD	YES	YES	YES
Toshiba	TS32	microSD	YES	YES	YES
Toshiba	TS650	microSD	YES	YES	YES
Toshiba	TX62	miniSD	YES	YES	YES
Toshiba	TX80	microSD	YES	YES	YES
Toshiba	W45T	microSD	YES	YES	YES
Toshiba	W47T	microSD	YES	YES	YES
VK	Kickflip	microSD	YES	YES	YES
VK	VK7000	MMCmicro	YES	YES	YES
Xcute	DV50	miniSD	YES	YES	YES